

Armadillo Mask

Making 12

www.silentqueen.com


This is a step-by-step workbook for making twelve Armadillo Masks. *This mask has two fabric layers that form an inside pocket to insert a removable third non-woven material layer. This mask is not a medical mask. It follows the CDC guidelines and French health officials recommendations. Their advice is that cloth masks should ideally be made in **cotton**, be **triple-layered**, have **no sagittal seam** (vertical seam on the nose) and be **washable** at hot temperatures.*

This workbook is intended to be used by intermediate makers.

So, let's make Armadillo masks for the community!

What you need

- Basic sewing kit (*pins, needles, scissors, marking pen, seam ripper...etc*)
- Rotary cutter or scissors
- Cutting mat
- Measuring tools
- 1m to 1.2m of 100% firmly woven cotton (see cutting layouts for yardage)
- 24 elastic ties for ear loops (15 to 23 cm depending on the head size and the stretch in your elastic)
- **or** 24 fabric ties for head ties (5cm x 75cm)
- **or** 12 fabric ties for a long tie with a neck loop (100 - 130cm)
- Nose bridges (pipe cleaners, twisted garden wire...etc)
- Magic Spray (1/2 white vinegar - 1/2 water)



Process

1 - Preparing and cutting your fabric

2 - Closing the mask

3 - Forming the nose bridge casing

4 - Shaping the pleats

5 - Sewing the first strip

6 - Inserting the nose bridge

7 - Sewing the second strip

8 - Adding elastic loops

App: Cutting Layouts


1 - Preparing and cutting your fabric

The best material for masks is a **light but firmly woven 100% cotton**. **Percale** often used for home linen (sheets and duvet covers) and **poplin** are good choices if you have some. Although a bit heavy, **quilting cottons** are also suitable. A loose weave won't provide adequate protection. Your fabric should be able to resist a **wash at a temperature of 60 degrees minimum** for a cycle of at least 30 minutes.

- **Wash** your fabric
- **Press** your fabric
- **Study the cutting layouts** at the end of this workbook for the best cutting options (*You can save a lot of material if you take some time to optimise your cutting by placing your pattern pieces in the most efficient manner.*)




Trace using cutting layouts



Cut all panels and strips

- Trace and cut out **12 panels** and **24 strips** using rotary cutter or scissors.
- You can also at this point **cut your ties if you want to make them out of fabric**. Whether fabric bias or T-shirt strips, 4 to 5cm width is sufficient and your final ties should be around **75cm long for two ties, 100 - 130cm for a single tie**. The best is to try different widths and make samples before cutting your ties.



*Cut **12 panels** 19cm x 35cm and **24 strips** 7.5cm x 10cm*

2 - Closing the mask

- Fold each panel in half **right sides together** (*print on print*).
- Pin, **placing your 2 pins at approximately 5.5cm from each edge**.
- Stitch the top of the mask. **Seam allowance is 1.2cm**. Make sure you **backstitch on each side of the filter opening**. (*There is no need to be too precise, you do not have to use pins, you can simply fold your panels and eyeball the stitching. Make sure the gap is big enough for a filter to be inserted*)
- Press open.



Place your pins to mark the filter opening



Press the top seam open

3 - Forming the nose bridge casing

- **Topstitch** one of the seam allowance sides (any side is fine) making sure you do not sew more than one layer. **Whichever side you do NOT topstitch will be the top of your mask** where you will insert the **nose bridge**.



Topstitch one side of the SA



Be careful to only sew one layer

- **Fold the top of the mask** forming a casing wide enough for the nose bridge. Press.
- **Topstitch** the nose bridge casing.



Form the casing for the nose bridge



Topstitch the nose bridge casing

4 - Making the pleats


- Place the mask face down on your ironing table with the nose casing at the top. Fold the mask in half (**horizontally**), press to form a **central crease**. Open the mask.
- Fold again to **align the top and bottom halves to the centre line**. Press the two newly formed creases. Be careful not to press the central crease flat. You now have **3 creases**.



Fold in half



Fold again and align to the central line



The 3 creases marked

- Turn the mask over. On the outside of the mask, **tuck the pleats under** so that they are facing away from the top. They should be pointing down on the final mask.
- **Magic Spray** and press. The vinegar/water solution helps to mark the pleats sharply and hold them in place.
- **Pin the pleats** on both sides, away from the edge. Measures can be approximative but if you fold your mask in 1/2 (pleats on pleats), you can make sure they are **more or less even**.



Tuck the pleats under



Magic spray!



Pin the pleats

5 - Making the side strips

- **Fold top and bottom edge** of each strip. Measurement is not too important at this stage as you'll be able to adjust lengths in the next step. **Magic spray** and press.
- Fold the strips in half (**lengthwise**). **Magic spray** and press.



Fold top and bottom of each strip




Fold each strip in half

First strip

- Pin the first strip **on the back side of the mask panel**.
- **Sew in place** (0.6 cm or so seam allowance). Press open.



Pin the first side strip on the back side of the mask



Press open

Insert the nose bridge

- **Insert the nose bridge in the casing.** *The best is to use metal nose bridges if you can find them. They can be salvaged out of single-use masks and recycled in cloth masks. You can also use garden ties (some are thick and very flexible). Pipe cleaners are another alternative. Some file fasteners are suitable but most of them are too sharp and can cut your fabric. Be creative.*
- Once inserted, secure the nose bridge in place with **a tack on both sides.**




Insert the nose bridge



Secure the nose bridge in place

Second strip


- Sew the second strip **on the back side of the mask.**
- Press open.



Sew the second strip in place. Press open

8 - Adding the ties

- Tuck the elastic length **under** the seam allowance and **fold the strip over** to enclose it.




Place the elastic in the seam allowance

- Close the casing by stitching **on the front of the mask**.
- Make a knot and **rotate the elastic loop to hide the knot** in the casing.



Rotate and hide the knot inside the casing



12 Armadillo masks ready to go!

*This workbook was developed by Kate Grace.
You can find Kate at www.silentqueen.com and on Instagram @s.i.l.e.n.t.q.u.e.e.n*

*Special thanks to **Louis Grace** who checked Kate's originally obscure instructions and sorted out the cutting layouts.*

*Kate is a French native living in New Zealand since 1995. She is on a journey to leading a slower, more examined life. She started **Silent QUEEN** to share that journey with others. She wants to provide actionable tips for people who are looking to add meaning to their life through "making".*

Appendix: Cutting layouts for 12 Armadillo Masks

A fabric has two selvages and two cut edges.


The selvage is the woven edge that does not fray (with factory finish, printed with design info...etc).

Fold your fabric right sides together, lengthwise, aligning selvage on selvage.

For 12 masks :


- if the width of your fabric is 90cm, you will need a length of 130cm
- for a width of 120cm, a length of 90cm
- for a width of 140 cm, a length of 80 cm
- for a width of 160 cm, a length of 70 cm

If you are recycling fabric, it will be more difficult to optimise the cutting but it is better if the **length of your masks follows the grain line** of your fabric (warp).




Each layout shows the fabric ALREADY folded in 1/2.


Full width 90cm



Full width 120cm



Full width 140cm



Full width 160cm

